

SVIVE®

**TRITON
ULTRATHIN**

**MECHANICAL GAMING
KEYBOARD**

Imported by Svive, Østre Kullerød 4
N-3241 Sandefjord, Norway | svive.gg

Introduction

Slive Triton Ultrathin is your key to successful gaming. Slive Gaming has designed the ultimate Nordic gaming keyboard for an even better gaming experience. Take full control of your opponents with precise mechanical switches that won't let you down. Your new Triton RGB keyboard connects easily and takes you to the next level without lag. Triton Ultrathin is a mechanical RGB keyboard with 96 keys. Offering two-color keycaps, RGB backlight, control of hardware backlight, and FN multi-function key combination.




Product size	342x124x22mm±2mm	Packaging content
Keyboard standard	96 key mechanical keyboard	1x Mechanical Keyboard
Backlight	RGB	1x Keycap puller tool
Keyboard Material	Metal + ABS	8x Extra keycap set
Keycap	PBS Two-color injection	1x User manual
Axial	Blue/Red/Brown/Speed	System support
Working voltage	5V	Windows XP / Vista / 7 / 8 / 10, IOS, MacOS, Linux, Android

Dual System Support

Fn+A Switching to Windows OS Mode. (Please refer to the table below for functions)

Fn+S Switching to Mac OS Mode. (Please refer to the table on the next page for functions)

Key functions



	Win	Mac		Win	Mac
Fn+F1	Computer	☼	Fn+F7	Play/pause	⏮
Fn+F2	Web	☼	Fn+F8	Stop	⏮
Fn+F3	E-mail	✉	Fn+F9	Volume+	⏭
Fn+F4	Music	🎵	Fn+F10	Mute	🔇
Fn+F5	Last one	⏮	Fn+F11	Volume-	⏭
Fn+F6	Next one	⏭	Fn+F12	Calculator	🧮

Fn+A	Win mode
Fn+S	Mac mode
Fn+Tab	Bluetooth/USB
Fn+B	Bluetooth pairing
Fn+Win	Lock win key
Fn+Del	Backlight set.
Fn+ /	Sidelights set.
Fn+Backspace	Custom backlight
Fn+Esc	Reset(3sec)

Backlight Settings

Fn+I FPS Game mode; 6 keys glow (W/A/S/D/↑/↓/←/→).

Fn+2 LOL Game mode; 14 keys glow (1/2/3/4/5/6/Q/W/E/R/A/S/D/F).

Fn + 3 Office mode, 26 character & Punctuation key glow.

Fn+backspace Custom backlight

While in one of the three modes mentioned above, press **Fn+backspace** to turn on the custom backlight settings. Click to light up, press again to turn off; after setting, press **Fn+ backspace** again to save and exit.

Fn +Delete 17 backlight effects available.

Fn+↑ Increase backlight brightness; five-stage adjustment.
Fn+↓ Decrease backlight brightness; five-stage adjustment.
Fn+← Decrease backlight speed; five-stage adjustment.
Fn+→ Increase backlight speed; five-stage adjustment.
Fn+ /

Other settings

Fn+Esc Reset (Press 3 secs).
Fn+Win Lock/ Unlock the Windows key function.